

## Hydrogen Peroxide (0-750 PPM) 100strips/vial

KU# F24-HYDGN-000750-VPS

CAT# HP-750 Hydrogen Peroxide test paper (0-750 PPM)



### OVERVIEW

HP-750 test kits are calibrated to measure the concentration of hydrogen peroxide in solution between 0 and 750 ppm with match points at 0-100-250-500-750 ppm.

### PRODUCT DIRECTIONS

- Dip strip into test solution for 1 second.
- Remove strip and shake off excess.
- Match at 90 seconds to color chart.