

# INTERCOM AMBULANCE/RESCUE VEHICLE MODEL ICA100 SURFACE MOUNT SERIES MODELS ICA200, ICA300 FLUSH MOUNT SERIES MODELS ICA400, ICA500



ICA100









#### FIRE RESEARCH CORPORATION

www.fireresearch.com 26 Southern Blvd., Nesconset, NY 11767 TEL 631.724.8888 FAX 631.360.9727 TOLL FREE 1.800.645.0074

1

# CONTENTS

## **Table of Contents**

CONTENTS	2
INTRODUCTION	3
Overview	3
Features	3
Specifications	3
GENERAL INSTALLATION NOTES	4
ICA100 SERIES INSTALLATION	5
Pre-Installation	5
Install Remote Station	5
Install Master Station	5
ICA200/300 SERIES INSTALLATION	8
Pre-Installation	8
Install Remote Station	8
Install Master Station(s)	8
ICA400/500 SERIES INSTALLATION	12
Pre-Installation	12
Install Remote Station	12
Install Master Station(s)	12
OPERATION	16
Basic Two-Way System	16
Basic Three-Way System	16
System Options	
Operational Check	

## **List of Tables**

Table 1.	Intercom	Specifications	3
----------	----------	----------------	---

# **List of Figures**

ICA100 Mounting Dimensions	6
ICA100 Wiring	7
ICA200/300 Adjustable Mount	9
ICA200/300 Mounting Dimensions	9
ICA200 Wiring	10
ICA300 Wiring	11
ICA400/500 Mounting Dimensions	13
ICA400 Wiring	14
ICA500 Wiring	15
	ICA100 Wiring ICA200/300 Adjustable Mount ICA200/300 Mounting Dimensions ICA200 Wiring ICA300 Wiring ICA400/500 Mounting Dimensions

## INTRODUCTION

## Overview

Fire Research intercoms are designed to meet rescue and fire service requirements for two or three-way voice communications system. The ICA100 series intercom systems are designed for use inside ambulances and rescue vehicles. The ICA200/300 surface mount and ICA400/500 flush mount series intercom systems are weather-resistant and specifically designed for outside use on fire service apparatus.

## Features

Master station with volume and push-to-talk controls

Remote station is operated hands free

Dual master stations for three-way systems

Adjustable mount (ICA200/300 Series)

Hand-held microphone option for master stations

Foot switch option for master stations

# Specifications

### Table 1. Intercom Specifications

SERIES	ICA100	ICA200/300	ICA400/500				
SUPPLY VOLTAGE	12 VDC	12 VDC	12 VDC				
OUTPUT POWER	8 WATTS	16 WATTS	16 WATTS				
FUSE	3 AMP RECOMMENDED	3 AMP SLOW BLOW .25" X 1.25" MDL	3 AMP SLOW BLOW .25" X 1.25" MDL				
DIMENSIONS MASTER (IN INCHES)	5.25 x 4 x 1.5	8.25 x 5.625 x 3 (Without Bracket)	6.25 x 7.25 (Panel Dimensions) <b>3" Clearance Required Behind Panel</b>				
DIMENSIONS REMOTE (IN INCHES)	4.25 x 3.25 x 1.5	5.25 x 5.25 x 2.25 (Without Bracket)	5.625 x 6 (Panel Dimension) 2.5" Clearance Required Behind Panel				
Handheld Microphone	N/A	Optional	Optional				
PTT Button for Remote Station	Optional	Optional	Optional				

## **GENERAL INSTALLATION NOTES**

Mount the intercom stations in locations that are safe and convenient for use.

It is recommended that the master station be mounted inside the cab.

Consider potential background noise that the hands free remote station might pick up.

If excess background noise is picked up by the hands free remote station due to vibration, mounting it on a rubber pad can help reduce noise.

Ensure a good ground connection. Isolate the intercom ground wire from other grounds that can be noisy (strobes, radios, priming motors, etc.).

Make interconnecting cable runs as short as possible.

Secure excess intercom cable in a figure 8 pattern.

The foot switch option requires the installation of a single-pole single-throw switch (not supplied with intercom).

## **ICA100 SERIES INSTALLATION**

## **Pre-Installation**

- 1. Measure and mark station locations for two mounting holes. Refer to Figure 1 for layout and dimensions.
- 2. Drill two 3/4-inch mounting holes at each station location.
- 3. Install the four conductor cable between station locations.
- 4. Remove nuts from mounting post on intercom boxes.

# **Install Remote Station**


- 1. Place station box in position with mounting post through the holes and secure with two nuts. (The nuts should be hand tight plus 1/4 turn.)
- 2. Connect station box four wires to cable. Refer to Figure 2 for wiring details.

# **Install Master Station**


- 1. Place station box in position with mounting post through the holes and secure with two nuts. (The nuts should be hand tight plus 1/4 turn.)
- 2. Connect station box four wires to cable. Refer to Figure 2 for wiring details.
- 3. Connect black wire to ground.
- 4. Connect red wire to +12 VDC.

### Master Station


Two 3/4" holes are needed.



**Remote Station** 



# Figure 1. ICA100 Mounting Dimensions






Figure 2. ICA100 Wiring

## **ICA200/300 SERIES INSTALLATION**

**Note:** In a three-way system (ICA300) master station A has transmit priority over master station B and the remote station.

Note: Mounting hardware is not included, 1/4-inch hardware is recommended.

# **Pre-Installation**

- **Note:** The mounting bracket can be removed by unscrewing the adjustment knobs at the side of the station box (Refer to Figure 3).
  - 1. Measure and mark station box locations for mounting bracket installation. Refer to Figure 4 for layout and dimensions.
  - 2. Drill four mounting holes at each station box location for mounting hardware.

- 3. Install the cable (with 3-pin connector) between remote and master station box locations. Refer to Figure 5 or 6 for wiring details.
- 4. For three-way system (ICA300) install the cable (with 5-pin connector) between master stations A and B box locations. Refer to Figure 6 for wiring details.

# **Install Remote Station**

- 1. Place mounting bracket in position and secure with four screws.
- 2. If bracket was removed from box, place remote station box in position and install rubber bushings and mounting knobs.
- 3. Connect station box 3-pin Molex connector to cable connector.

# Install Master Station(s)

- 1. Place mounting bracket(s) in position and secure with four screws.
- 2. If bracket was removed from box, place master station(s) in position and install rubber bushings and mounting knobs.
- 3. Connect station box 3-pin Molex connector to cable connector.
- 4. For three-way system (ICA300) connect station box 5-pin Molex connector to cable connector.
- 5. Connect black wire to ground.
- 6. Connect red fused wire to +12 VDC.
- 7. For three-way system repeat steps 4 through 6 at master station B.

**Note:** Pre-installed apparatus wiring can be used. The intercom connections are one-to-one. The yellow wire is shield.







Figure 3. ICA200/300 Adjustable Mount





If the PTT option is installed on the remote station a 5-pin Molex will be used.



# Figure 6. ICA300 Wiring

## ICA400/500 SERIES INSTALLATION

**Note:** In a three-way system (ICA500) master station A has transmit priority over master station B and the remote station.

Note: Mounting hardware is not included, number 10 hardware is recommended.

# **Pre-Installation**

- 1. Measure and mark station box locations for panel opening and four screw holes. Refer to Figure 7 for layout and dimensions.
- 2. Drill four mounting holes at each station box location for mounting hardware.
- 3. Cut out panel opening at each station location.

**Note:** Pre-installed apparatus wiring can be used. The intercom connections are one-to-one. The yellow wire is shield.

- 4. Install the cable (with 3-pin connector) between remote and master station box locations. Refer to Figure 8 or 9 for wiring details.
- 5. For three-way system (ICA500) install the cable (with 5-pin connector) between master stations A and B box locations. Refer to Figure 9 for wiring details.

# **Install Remote Station**

- 1. Place station box in position and secure with four screws.
- 2. Connect station box 3-pin Molex connector to cable connector.

# Install Master Station(s)

- 1. Place station box(es) in position and secure with four screws.
- 2. Connect station box 3-pin Molex connector to cable connector.
- 3. For three-way system (ICA500) connect station box 5-pin Molex connector to cable connector.
- 4. Connect black wire to ground.
- 5. Connect red fused wire to +12 VDC.
- 6. For three-way system repeat steps 3 through 5 at master station B.

Master Station Cutout and Mounting Holes






Figure 7. ICA400/500 Mounting Dimensions



If the PTT option is installed on the remote station a 5-pin Molex will be used.



## OPERATION

### **Basic Two-Way System**

The basic two-way intercom system includes a master station with volume and Push-To-Talk (PTT) controls and a remote station that is operated hands free. The remote station is always transmitting unless interrupted by a transmission from the master station.

## **Basic Three-Way System**

The basic three-way system includes two master stations (A and B) with volume and PTT controls and a remote station that is operated hands free. The remote station is always transmitting unless interrupted by a transmission from a master station. Master station A has transmit priority over master station B and the remote station.

# **System Options**

### Handheld Microphone Option

This option is for installations in high noise areas. The microphone plugs into a receptacle on the station box. The system can be keyed to transmit with the microphone switch or the PTT button on the station box.

### **Remote Station with PTT Button Option**

This option is for installations where a remote station with hands free operation is not required. The PTT button will have to be pressed for the remote to transmit.

### **Foot Switch Option**

This option requires the installation of a single-pole single-throw foot switch (not supplied with intercom). A two conductor cable is wired at the foot switch and connected at the station box with a 2-pin Molex connector. The system can be keyed to transmit with the foot switch or the PTT button on the station box.

## **Operational Check**

### **Basic Two-Way System**

- 1. Turn on 12 VDC power.
- 2. Press and hold PTT button on master station box.
- 3. Speak into the box and adjust volume knob for transmit and receive level.

Result: Voice is heard at remote station.

- 4. Release PTT button.
- 5. Speak into remote station box.

Result: Voice is heard at master station.

### **Basic Three-Way System**

- 1. Turn on 12 VDC power.
- 2. Press and hold PTT button on master station A box.
- 3. Speak into the box and adjust volume knob for transmit and receive level.

Result: Voice is heard at remote station and master station B.

- 4. Release PTT button.
- 5. Press and hold PTT button on master station B box.
- 6. Speak into the box and adjust volume knob for transmit and receive level.

Result: Voice is heard at remote station and master station A.

- 7. Release PTT button.
- 8. Speak into remote station box.

Result: Voice is heard at master station A and master station B.

### Handheld Microphone and Foot Switch Option

Perform basic system test. For a station with either option, repeat the steps that key the system with the PTT button using the microphone switch or foot switch.

### **Remote Station with PTT Button Option**

Preform basic system test. For a station with the option press and hold the PTT button to speak into the box.

