Karat Analyzer

GT Series



Principle

Specific gravity of the sample & distinguish the real precious metal from the fake material.

Ease

Thanks to inbuilt measuring software which makes it operations easy.

Application

Gold Valuer I Jewellery Showroom I Bank & Financial Institution I Fake Gold

FUNCTIONS:

GOLD

• User can select either copper or silver individually as mix material in GOLD for purity measurement.

PLATINIUM

 User can select either palladium or Ruthenium or Cobalt individually as mix material in PLATINUM for purity measurement.

Advantages

- To Detect Fake Gold Jewellery
- Precious Metal Karat Tester Evaluating the purity of GOLD in % / Karat.
- Non-destructive.
- precious metals like Platinum & Silver can be tested by Optional mode.
- Can be used as a normal scale or Densimeter.

Detector				
Model	CY 323GT	CY 613GT	CG 612GT	CG 3102GT
Capacity	320 g	610 g	610g	3100g
Weighing Redability	0.001 g	0.001 g	0.01 g	0.01 g
Purity Karat	Gold 9-24 Karat with increment of 1 karat / Platinium 600-1000 pt with increment of 50 pt, % and Densit			
Minimum Sample Weight	2 g	2 g	5 g	10 g
Weight in Air Pan Size	108 x 100			160 x 140
Weight in Water Pan Size	100 x 92			160 x 140
Windshield	Yes		NA	NA
Display	Bright LCD Display with LED backlite			
Operating Temperature	10°C to 30°C			
Dimension (WxDxH)	342 x 212 x 270			342 x 212 x 230
Power Supply	AC Adapter 100V-240V +/- 20% 50-60Hz			
Net Weight with Packing	8.0 kg			8.0 kg
Packing Dimension	500 x 380 x 510			500 x 380 x 230
Constraint	Samples • With holes or hollow in nature • With any stones or diamond			
	 Mixed with metals which has very close density to Gold & Pt. 			