

Sulphite
Code : XL-116
Range : 2 - 40 ppm as SO_3

AQUA-XL
Water Analysing Kits

Directions for use :

1. Take 25 ml of water sample to be tested in the Test jar.
2. Add 17 – 18 drops of Reagent SI-1. Mix contents well.
3. Add 8 drops of Reagent SI-2 and mix well.
4. Now add Reagent SI-3 drop wise, counting the number of drops while mixing until **the BLUE colour appears.**

Calculations

Sulphite as ppm SO_3 = 2 x Number of drops of Reagent SI-3.

Sulphite
Code : XL-106
Range : 5 - 100 ppm as SO_3

AQUA-XL
Water Analysing Kits

Directions for use :

1. Take 10 ml of water sample to be tested in the Test jar.
2. Add 7 – 8 drops of Reagent SI-1. Mix contents well.
3. Add 3 drops of Reagent SI-2 and mix well.
4. Now add Reagent SI-3 drop wise, counting the number of drops while mixing until **the BLUE colour appears.**

Calculations

Sulphite as ppm SO_3 = 5 x Number of drops of Reagent SI-3.